

TRIPLE PLAYER ASSEMBLY INSTRUCTIONS

1-REMOVE BATTERY COVER & INSERT BATTERIES (MAKE SURE POLARITY IS CORRECT + TO +)



2 – REPLACE BATTERY COVER



3 – INSERT SPIKES INTO GROUND AS FAR AS POSSIBLE



4 – TAKE WIRE AND INSERT PLASTIC INTO HOLE IN TOP OF PLAYER



5 –REPEAT FOR OTHER 2 WIRES



6 – TAKE GREEN CONE AND INSERT INTO PEG HOLE OF DECOY



7 – PUSH FULLY HOME



8 – IF REQUIRED SCREW HOME IN DESIRED POSITION WITH 2 SELF TAPPERS, REPEAT FOR OTHER 2 DECOYS



8 – PLACE DECOYS ONTO ENDS OF WIRES



9 – SWITCH ON WITH WHITE SWITCH



AND THAT'S THAT- SEE VIDEO FOR OPERATION

HAPPY HUNTING

HAD 30 CROWS USING ONE OF THESE YESTERDAY AFTERNOON.

